

### Overview

With older AV Revolution firmware (prior to 2.14) the Master Override “Route Mic/Line4 to All” function routed the Mic/Line 4 signal path before the Zone Master volume control (pre-master). This was not the intended or required function.

Users may now configure the “Route Mic/Line4 to All” function as Pre-Zone Master or Post-Zone Master level control. This new configuration option is now provided in firmware version 2.14 and application GUI 2.16.

### Configuration

A new drop-down selector now appears when the “Route Mic/Line4 to All” action function is selected. Selecting “Pre-Zone Master” routes the Mic/Line 4 priority audio before the Zone Master level control. Selecting “Post-Zone Master” routes the Mic/Line 4 priority audio after the Zone Master level control.



**Pre-Zone Master**



**Post-Zone Master**

Pre/Post Master selection is also provided with the External Trigger source priority method.

The “Duck Depth” control sets the level of all other inputs when the Master Override is active, assuming “Mute All Inputs” is not also selected.

The “Override Signal Level” control sets the Mic/Line 4 level. This control replaces the Mic/Line 4 fader on the main page, which is hidden when Master Override is enabled.