# Z624 FOR BASIC ZONING WITH PAGING




**INPUT PRIORITY**
Set the priority for inputs 1 & 2 over inputs 3 to 6 on the rear panel

**Z624PS**
Connected to any Acc port 1

**PAGING PRIORITY**
Set the Paging Priority for the Z624PS in the software

**FRONT PANEL CONTROL**
- Input routing is done by selecting Zone A, B, C or D for each input.
- Adjust the input and output level as required.

**TRUEBLU**
Programmable Bluetooth receiver

**HS4250P**
4 x 250W high or low impedance




**ROUTING**
- Set the routing mode in the software to either Mixer or Matrix.
- **MIXER MODE - DEFAULT**
  Multiple inputs can be sent to each Zone
- **MATRIX MODE**
  Only one input can be routed to a Zone at a time